



## Icon Downloading Jukebox Quick Start Guide (U.S. Version)

- **Install hard drive**  
Be sure drive connectors are clean, is fully seated and no pins are bent.
- **Install Internet equipment.**  
Connect Ethernet cable to Ethernet Port on Core Computer.
- **Connect speakers** per Connecting Speakers document.
- **Connect volume control** per instructions in service manual. *Connector inserts from top.*
- **Apply AC Power**  
Machine will re-boot 3 times.
- **Calibrate Touch Screen**  
When the normal album display screen appears, **push the Screen Calibrate button.** Following the on screen guide, set sensitivity to -2. (Hint; *minus is more sensitive.* You can test the screen sensitivity by touching inside the on screen guide. The picture will “light up” to your touch. Adjust if necessary.) Push the Screen Calibrate Button again, close the door, then touch the 9 on screen targets making sure each turns into a green checkmark on your touch. Touch CONFIRM. Touch Quit. If there are problems when touching the targets or touching the confirm button, try setting the sensitivity to -3.
- **Access Service Console** by pushing the SERVICE Button.
- Touch System Settings and Diagnostics > Diagnostics > View Hardware Status.  
**Check 3.3 Volt, 5 Volt, 12 Volt and Cooling fan status.** Touch Back.
- **Touch Test Hardware Signals.**  
Touch Test Cabinet Fans. Be sure fans operate.  
Insert Coins and Bills. Be sure they increment counters.  
Touch Back
- **Touch Test Network Status**  
Touch Test Gateway. Wait for test to finish.  
Touch Test Ecast. Wait for test to finish.  
Touch RPC Server. Wait for test to finish.  
**Make sure all tests passed.**  
Touch Home.
- **Set Amplifier Defaults**  
Touch System Settings and Diagnostics > Configure Amplifier > Reset Factory Defaults > Reset Now > OK. When “Audio settings reset complete” appears, touch Back. Touch Configure Amplifier > Set Equalizer Levels and AVC > AVC Off.  
Touch Home. **This one is very important to do!**

The jukebox is now ready for basic operation.

You may wish to **set** Music Filters, **Remote Control Options**, Pricing and Play Options.